

ASPHALT OR CONCRETE, THE CHOICE IS YOURS.

Sidewalk maintenance doesn't stop when the snow melts. Winter freezethaw cycles can cause frost heave and wreak havoc on pedestrian walkways, creating differences in sidewalk elevations. These repairs are often outsourced to companies specializing in slab jacking (mudjacking), grinding or milling.

However, a public works department equipped with a Trackless MT and Cold Planer can repair concrete or asphalt surfaces in a cleaner, faster and more cost-effective manner, saving the municipality from unnecessary costs.

CONTACT TRACKLESS TODAY

CALL 519-688-0370

EMAIL info@tracklessvehicles.com

VISIT 55 Thunderbird Drive, PO Box 244,

Courtland ON, Canada NOJ 1E0

GENERAL SPECS

PLANING WIDTH 16" (406 mm)

PLANING DEPTH

0 to 6" (0 to 152 mm)

DRUM OPTIONS

Asphalt Drum (50 picks)

Concrete Drum (160 picks)

OPTIONSSpray Nozzle Kit

